

## CHMax New Channel List Instructions

### CHMax Setting




CHMax :[ON/OFF],set [ON],default [ON]

Channel List Style: [New/Original] n Switch new channel list andOriginal channel list default [ON]

#### NOTE:

1. For the STB without USB port, the channel icon will automatically do wnload via network.
2. For the STB with USB port, the channel icone will automatically down load via network and save in the USB disk. It will read the saved channel icon from USB disk when you switch to channel list menu.

# New Channel List Style



HOT KEY :

[RED] Sort channels list from A~~Z

[GREEN] Sort channels list in many different ways

[Filter] Filter channels list in many different ways

[BLUE] Go to Edit Channels menu


[EPG] Switch 1 column and 2 column

[Type] Switch channels Type:

:ALL CHnannels—》 FTA Channels →Scramble Channels →HD Channels-(→UHD Channels )

[FIND] Search keyword program

[0] Switch simple information and detail information



## Channel Info Bar

